

For installation on UL Listed Wood Fire Doors fill the through hole wire passage with UL Classified Fire Stop Sealant after connecting all wiring and testing the Lock

"KEYPAD/PROXREADER MOUNTING PLATE" TEMPLATE

For installing a Keypad/ProxReader Mounting Plate to the OUTSIDE ("unprotected" side) door surface

- For use on wood doors (for metal doors, use WI2371LF)
- For use with cylindrical locks
- DO NOT USE THIS TEMPLATE if a deadbolt or other obstruction is located above the lock (to avoid interference with Keypad/ProxReader operation)

IMPORTANT

WHEN PRINTING OR PHOTOCOPYING A TEMPLATE, ALWAYS SELECT PRINTING OPTIONS TO ENSURE THAT COPIES ARE PRODUCED **WITHOUT** SIZE ADJUSTMENTS.

VERIFY THE DIMENSIONS OF THIS BOX ARE 2.000 X 2.000 INCHES ± 0.010.

